

**MANUAL
FOR
DATA CAPTURE SOFTWARE**

INDEX

Introduction

a. System

- 1.1. Data Capture setting master
- 1.2. Card Master
- 1.3. Card writer
- 1.4. Reason card master
- 1.5. Set time(all machine)
- 1.6. Set Mail id
- 1.7. Set password

2. Capture

- 2.1. Data Capture
- 2.2. Multiple Data Capture
- 2.3. Online Data Capture

3. Biometric

- 3.1. Finger setup
- 3.2. Finger setup(with name)
- 3.3. Finger Writer(In card)

4. Masking

- 4.1. Machine Masking
- 4.2. Multiple Machine Masking
- 4.3. Online Machine Masking

5. Proximity

- 5.1. Proximity List send to Machine
- 5.2. Proximity Finger Setup

6. About us

7. Help

8. Exit

Introduction

Data capture software is the application software of time office software. With the help of data capture software; you can capture punching data from starlink attendance system and store it on a particular location of your computer and with the help of this punching data you can generate reports.

After installing the software you run it by double click on the icon of the data capture. A main window of data capture will appear on your computer screen as follows:



Figure 1.1: Main Data Capture

There are 8 sub menus in the data capture software which are given below:


- 1) System
- 2) Capture
- 3) Biometric
- 4) Masking
- 5) Proximity
- 6) About us
- 7) Help
- 8) Exit

1. System

By using this menu, you can set new machine setting, create card master, write cards from card writer, Create reason card, set time to many machine, set mail id master and set password.

I. Machine Setting

For capturing data from Machine, first you have to create new machine setting in data capture software.



Data Capture Setting Master

Machine Name

Connection Type

Select Com COM1 COM2 COM3 COM4

Bits/Sec

Machine Setting Auto Manual

Card Write Alignment Left Alignment Right Alignment

DataBase SQL Oracle FoxPro None

Temp File Path

Machine Location id

Auto Data Transfer From Machine in Every Minute
(Max Time Apply for Auto Data Transfer In All Available Machine)

Figure 1.2: Data capture setting master

There are 6 buttons on this machine settings window:

1. **New:** Press button New to create new machine setting for new machine.
2. **Edit:** Press button Edit to modify the existing machine setting.
3. **Delete:** Press button Delete to delete existing machine setting.
4. **Save:** Press button Save to save existing machine setting (in case you did any change in existing Machine Setting).
5. **Cancel:** Press button Cancel to cancel any modification in machine setting.
6. **Close:** Press button to close machine setting.

There is some compulsory area as following below:

1.1.1. **Machine name:** Enter a particular name to a particular machine.

1.1.2. **Connection type:** You can connect Star Link attendance systems with software through three way :

Starlink attendance systems have three type of connectivity with computer like

- a. serial,
- b. TCP/IP and
- c. modem

a. **Serial:** Select Connection type as " Serial" and Mark Check on "Com1" or "Com2" or "Com3" or "Com4"(Com port) with which system you want to connect the machine and select transfer rate of data in bits/sec.

The image shows a software dialog box titled "Data Capture Setting Master" with a light green background. It contains several configuration fields and buttons. At the top, the title "Data Capture Setting Master" is displayed in blue. Below it, there are several sections of controls:

- Machine Name:** A text input field.
- Connection Type:** A dropdown menu currently showing "SERIAL".
- Select Com:** Four radio buttons labeled "COM1", "COM2", "COM3", and "COM4".
- Bits/Sec:** A dropdown menu.
- Machine Setting:** Two radio buttons labeled "Auto" (selected) and "Manual".
- Card Write Alignment:** Two radio buttons labeled "Left Alignment" and "Right Alignment" (selected).
- DataBase:** Four radio buttons labeled "SQL", "Oracle", "FoxPro", and "None" (selected).
- Temp File Path:** A text input field with a browse button (three dots).
- Machine Location id:** A text input field.
- Auto Data Transfer:** A checkbox labeled "Auto Data Transfer From Machine in Every" followed by a text input field for "Minute". Below this is the text "(Max Time Apply for Auto Data Transfer In All Available Machine)".

At the bottom of the dialog, there is a row of six buttons: "New", "Edit", "Delete", "Save", "Cancel", and "Close".

Figure 1.3: Machine Setting for Serial Type Connection

b. TCP/IP: Select Connection type as " TCP/IP" and enter IP Address of the machine in TCP/IP textbox.

Data Capture Setting Master

Machine Name

Connection Type

TCP / IP Address

Machine Setting Auto Manual

Card Write Alignment Left Alignment Right Alignment

DataBase SQL Oracle FoxPro None

Temp File Path ...

Machine Location id

Auto Data Transfer From Machine in Every Minute
(Max Time Apply for Auto Data Transfer In All Available Machine)

Figure 1.4: Machine Setting for TCP/IP Type Connection

c. Modem: Select Connection type as " Modem" and mark Check on "Com1" or "Com2" or "Com3" or "Com4"(Com port) with which system you want to connect the machine and select transfer rate of data in bits/sec and enter phone number.




Figure 1.5: Machine Setting for Modem Type Connection

1.1.3. Machine Setting: You can use this option for setting in writing the card.

1. Auto: To check "Auto" for deducting setting of machine of the card configuration automatically, that is given by machine through it's own sense.

Manual: To check on "Manual" for deducting machine setting manually for card By using following options:

- **Five Digit Card:** If you want to write your card of 5 digits number, check on this checkbox.
- **Four Digit Card:** If you want to write your card of 4 digits number, check on this checkbox.
- **Eight Digit Card:** If you want to write your card of 8 digits number, check on this checkbox.

Note: Select the Option which is applicable to your attendance Machine and apply here.

1.1.4. Card Write Alignment: You can write card through two type of Alignments:

I. **Left alignment** is used for old machine. (Old motherboard).

II. **Right alignment** is used for new machine. (ARM board).

The screenshot shows the 'Data Capture Setting Master' dialog box. The title bar is green with the text 'Data Capture Setting Master' in blue. The dialog has a light green background. It contains the following fields and controls:

- Machine Name: Text box containing 'starlink'.
- Connection Type: Dropdown menu showing 'Modem'.
- Select Com: Radio buttons for COM1, COM2, COM3, and COM4. COM1 is selected.
- Bits/Sec: Dropdown menu showing '9600' and a text box containing '011420526088'.
- Machine Setting: Radio buttons for 'Auto' and 'Manual'. 'Manual' is selected.
- Card Write Alignment: Radio buttons for 'Left Alignment' and 'Right Alignment'. 'Right Alignment' is selected.
- DataBase: Radio buttons for 'SQL', 'Oracle', 'FoxPro', and 'None'. 'None' is selected.
- Temp File Path: Text box with a browse button (three dots).
- Machine Location id: Text box.
- Auto Data Transfer From Machine in Every: Checkbox (unchecked), text box, and the word 'Minute'.
- (Max Time Apply for Auto Data Transfer In All Available Machine): Text below the previous field.
- Buttons: 'New', 'Edit', 'Delete', 'Save', 'Cancel', and 'Close' at the bottom.

Figure 1.6: Machine Setting for Card Alignment

1.1.5. Data Base: Check on particular data base (SQL, Oracle, FoxPro, None)on which time Office software is running. If it is not applicable, check on box "None".

1.1.6. Temp File Path: This is a location where you want to send and store the text file of punches data in computer. When you will capture the punching data then it will

automatically send "Text file" to the particular location which you saved in temp file path.




Figure 1.7: Machine Setting for Auto or Manual


1.1.7. Machine Location Id: This option use if a company has many machines at many locations. In that case you have to give location id for a particular location machine which is unique.

1.1.8. Auto Transfer Data from machine in every ___minute: Check on this checkbox to capture data automatically from the machine to temp file path after the specified time, Which you specify in the minute box.

1.2. Card Master: Card master is used to create card list of proximity card or smart card.

1. In case of proximity card, you have to enter 10 digits unique no in the proxy card no textbox.
2. In the case of smart card, you have to enter 0 in the proxy card no textbox.

New: Press button New to create new card. Enter unique proxy card no., unique card no and name.



Proximity Card




Figure 1.8: Card Master

Enter first 10 digits no, you have to put in the given box and give a card number and name on this proximity card no. i.e. in the above proximity card you have to take first 10 digit number which is 0003116888 and enter it in the card master.

Edit: Press button edit to modify the existing card.

Search: There are two type of search process in the card master first is through "Card No." and the second is "Apro Card No." If you are choosing card no then you have to enter card no in the textbox, which you want to search. If you are choosing apro card no

Is group reason: In case when you check “is group reason”, if bus is late and a number of employee want to show the same reason, first guard will show a reason card and a number of employees will show cards and again show the reason card.
 Duration for first reason card and again reason card will be 5 minute, after 5 minute you have to do the same process again.
 In the case when a single employee comes late, simply show reason card and then attendance card.

1.5. Set Time to All Machines:

You can set time of many machines which hanged on different locations.
 Press button set time to all machine and system time will be set in all machines.




Figure 1.11: Set Time to All Machines

1.6. Set Mail Id:

If you have a machine at different location and by this setting when they will capture the data, a text report will automatically deliver to server.

The screenshot shows a 'Mail Information' dialog box with the following fields and values:

- Server IP:** 192.168.0.1
- From (Mail Id):** pankaj@starlinkindia.com
- To (Mail Id):** pankaj@starlinkindia.com
- Mail Subject:** datacapture
- Mail Sending Opt.:** 5. Using Outlook Object
- Mail Text:** data capture mail for research and developmant using option 5 by pankaj malik

Buttons at the bottom: Update, Close

Figure 1.12: Mail Information

Server IP: Give that server's IP address to which you want to send mail.

From(Mail id):Mail of that person from mail will come.

To(Mail id): Mail id of that person where mail will automatically come.

Mail Subject: Enter subject.

Mail sending option: This is the option from which you can send mail.

Mail Text: you can write mail text.

1.8 Set Password:

If you want to set password in data capture, simply give a user name and password and again the same password. When you will open the capture software, it will ask the user name and password.




Figure 1.13: Set Password of Data Capture

2. Capture: By using this menu, you can capture data from single machine, multiple machine and online punching data.

2.1. Data Capture: Through this data capture, you can transfer punching data from machine to temp file path which you saved in machine setting.




Figure 2.1: Data Capture

1. Machine Name: Select machine name from the list and IP address will automatically appear in IP address textbox and press button Connect to connect the machine. When machine is connected, two options will appear:

I) Dates of all punching data will show on **Data List** textbox. Select two dates by double click on data list and press button **Transfer** to transfer data from machine to specify location which you saved in temp file path of machine setting.

II) **Memory Utilized by reader is ___%**(means how much percentage memory has been used in machine) will show on respective textbox.

2. Select two dates from **date list** which will show in **from date** textbox & **to date** textbox and press button **Delete** to delete punching data from the machine.

3. **Set Time** :Enter Time and press button Apply to set time in the machine.

4. **Set Date**: Enter Date and press button Apply to set the date in the machine.

5. **Show System Date & Time**: Press button Show System Date & Time and system's date & time will show on respective textbox. Check "Set as per system Date/Time" and press button apply to set system's date & time in the machine.

6. **Disconnect**:Press button Disconnect to disconnect the machine.

7. **Version**:Press button Version to see the version of the machine.

8. **Close**:Press button Close to close data capture window.

2.2. Multiple Data Capture

If a company has many machines at many locations. By using multiple data capture, you can capture punching data from many machines at a time and punching data will store in tempfile path which you saved in machine setting.




Figure 2.3: Multiple Data Capture

Y states: Select state Y to activate the machine.

N states: Select state N to deactivate the machine.

From Date & To Date(dd/mm/yyyy): Enter "from date" & "to date" in textbox (proper format) to capture punching data.

Status: After pressing button Capture Data, if punching data has been transferred from machine, status will show "done". If process is not done, status'll show "error".

Capture Data: Press button Capture Data to capture punching data from many machine.

Close: Close multiple data capture window.

2.4. Online Data Capture

To select this option to capture punching data online but first check on **auto data transfer from the machine** and enter that **time duration in minutes** after which data will transfer automatically.




Figure 2.4 Online Data Transfer

b. Biometric

By using this menu, you can enroll finger with card, enroll only finger and card writer(finger print).

3.1 Finger Setup

By using this finger setup, you can register new finger (with existing smart card) from the software. All fingers data will be saved in computer. If sometimes machine will create problem, in that case you can transfer finger data from software to machine




Figure 3.1.a. Finger Set Up

1. Machine Name: Select machine name from the list and IP address will automatically appear in IP Address textbox and press button Connect to connect the machine.

2.Registration of new finger: There are following steps to register new finger :

i: Check **New Finger Registration** and enter Card no (in textbox below New finger register checkbox) with which you want to register finger.

ii: **Register:** Press button Register and message " **Put Finger**" will appear on the finger setup screen, put finger on the scanner and process will be done by the machine. That Finger data will show in "Computer data" and then press button **save>>** to save that finger in computer's database.

or

iii. If you don't want register finger with that card, enter card no and check on **Bypass finger**, press button Register to bypass finger from that card.

3.<<Send: Check on "Select All(or check on selective finger)" from computer side and press button <<send to send fingers data from computer to machine.

4.>>Delete: Check on "Select All(or check on selective finger)" from computer data side and press button Delete>> to delete finger data from the computer.

5.<<Delete All: Press button <<Delete to delete all finger data from the machine.


6<<Delete: Check on "Select All(or check on selective finger)" from Machine data side and press button press button <<Delete to delete finger data from the machine.

7.Version:Press button Version to see version of the machine.

8. Exit: Press button Exit to close finger setup window.

3.2. Finger Setup (with Name)

This setup is used in the registration of only finger. By using this finger setup (with name), you can register new finger from the software.



Finger 3.2. Only Finger

1. Machine Name: Select machine name from the list and IP address will automatically appear in IP Address textbox and press button Connect to connect the machine.

2. Registration of new finger: There are following steps to register new finger :

i: Check **New Finger Registration** and enter Card No in card no textbox on which you want to register finger enter name in name textbox and then press button save.

ii: **Register:** Press button Register and message "**Put Finger**" will appear on the finger setup screen, put finger on the scanner and process will be done by the machine. That Finger data will show in "Computer data" and then press button **save>>** to save that finger in computer's database.

3.<<Send: Check on "Select All(or check on selective finger)" from computer side and press button <<send to send fingers data from computer to machine.

of card no and name will automatically appear in the "Enter Name for Search" textbox.

3. Press double click on card no & name, both card no & name will automatically appear in **Card No.** textbox and **Name** textbox respectively and press button Write to write the card.

c. Masking :

Masking is a function which is used to restrict area for the employee. By setting this masking option, you can set masking for an employee for any location and that employee can't enter in that area.

By using this menu, you can set machine masking, multiple machine masking & online machine masking through software.

4.1. Machine Masking

This option is used for single machine masking.

Eight Digit Masking Data Update

Machine Name: ttt [Connect]

TCP/IP Address: 192.168.0.78

Machine Data	
Card No	
<input checked="" type="checkbox"/> 99999999	

Computer Data	
Card No	
<input checked="" type="checkbox"/> 34551	

<< Send

<< Delete

Update Machine

Exit

Figure 4.1: Machine Masking

1. **Machine Name:** Select machine name from the list and IP address will automatically appear in IP address textbox and press button Connect to connect the machine.

2. When machine will be connected, card list (made in card master) will show in computer data side.

3. check on Select All(or selective cards no.) checkbox and press button <<**send** that card data to machine, press button **Update machine** to update the machine.

4. Press button <<**Delete** to delete card list from the machine.

5. **Exit:**Press button Exit to close the machine masking window.

4.2. Multiple Machine Masking

If a company has many machines at many locations. By using multiple machine masking option, you can set masking of card list in multiple machines at the same time.

Mask	Machine Name	IP Address	Status
Y	A	192.168.0.17	
Y	AA	192.168.0.55	
Y	sde	192.168.0.58	
Y	ss	192.168.0.57	
Y	ttt	192.168.0.78	

34551

Transfer Data Close

Figure 4.2: Multiple Machine Masking

Y states: Select state Y to activate the machine.

N states: Select state N to deactivate the machine.


Double click on "Mask" column to select **Y** or **N** to set machine activate or deactivate.

Transfer Data: Check on card no and press button Transfer Data to that card list to multiple machine.

Close: Press button Close to close the Multiple machine masking window.

4.4. On Line Masking

This option is used for online masking of cards .



Mask	Machine Name	IP Address	Sta
Y	A	192.168.0.17	
Y	AA	192.168.0.55	
Y	sde	192.168.0.58	
Y	ss	192.168.0.57	
Y	ttt	192.168.0.78	

Figure 4.3: Online Masking

Y states: Select state Y to activate the machine.

N states: Select state N to deactivate the machine.

Double click on "Mask" column to select **Y** or **N** to set machine activate or deactivate.

Enter time of transfer : Enter time of transfer after which masking will start online and press button Apply.

Note: Enter time of transfer will work according to computer's time. If computer time is 12:30 pm and if you want to start online masking, you have to enter time like 12:45pm in **Enter time of transfer** textbox and press button Apply to start masking after 12:45pm.

5. Proximity

By using this menu, you can send proximity list to all machine and enroll new finger with proximity card.

5.1. Proximity List Send To All Machine

In the card master, you created proximity card list. When you'll open sub menu "proxi list send to machine", that proximity card list will show. Press button **Send to Machine** to send that card list to all machine at the same time.




Figure 5.1: Proximity Card List send to Machine

Y states: Select state Y to activate the machine.

N states: Select state N to deactivate the machine.

Send to Machine: Press button Sent to machine to send Card list to machine.

Close: Press button Close to close Proxi list send to machine window.

5.2. Proximity Finger Print Transfer

By using this proximity finger setup, you can register new finger (with existing proximity card) from the software. All fingers data will be saved in computer. If sometimes machine will create problem, in that case you can transfer finger data from software to machine.




Figure 5.2: Proximity Figure Print Transfer

1. Machine Name: Select machine name from the list and IP address will automatically appear in IP Address textbox and press button Connect to connect the machine. When machine will connect, proximity card list will automatically appear on proximity finger setup window.

2. Registration of new finger: There are following steps to register new finger :

i. Check **New Finger Registration** and enter Card no (in textbox below New finger register checkbox) with which you want to register finger. Or Double click on existing card in proximity card list and card no will automatically appear in textbox (below new finger register checkbox).

ii. **Register:** Press button Register and message **"Put Finger"** will appear on the finger setup screen, put finger on the scanner and process will be done by the machine. That Finger data will show in "Computer data" and then press

button **save>>** to save that finger in computer's database.

iii. If you don't want register finger with that card, enter card no and check on **Bypass finger**, Press button Register to bypass finger from that card.

3. <<Send: Check on "Select All (or check on selective finger)" from computer side and press button <<send to send fingers data from computer to machine.

4. >>Delete: Check on "Select All (or check on selective finger)" from computer data side and press button Delete>> to delete finger data from the computer.

5. <<Delete All: Press button <<Delete to delete all finger data from the machine.

6.<<Delete: Check on "Select All(or check on selective finger)" from Machine data side and press button press button <<Delete to delete finger data from the machine.

7. Version:Press button Version to see version of the machine.

8. Exit: Press button Exit to close finger setup window.

6.About us :



7. Help

If you need some help regarding data capture software, use this option.

8. Exit

It will quit you from the Software.